

ArmaKleen Technical Service Report Summary

Cleaning Trial Type: Aqueous

Industry: Sharpening Services

Segment: 1 Auto Maintenance

Soil: Plastic, fiberglass

Substrate: Steel

Description of Part(s): Saw blades

Customer objective: Improve cleaning performance

Cleaner used:

- 100% by volume ArmaKleen™ Paint & Ink Remover
- 5% by volume ArmaKleen™ BIO-24

Machine used: Ultrasonic Washer (SK Blackstone 6315)

Temperature used: 160°F

Time required: 90 minutes

Post Cleaning: Fresh water rinse and air pressure dried

Recommendation to Customer: The ArmaKleen Technical Center recommends using a 5% by volume of ArmaKleen™ Bio24 at 160°F in an Ultrasonic Washer for a minimum of 90 minutes

Before Picture



After Picture



Source: TSR #19-A-091