

ArmaKleen Technical Service Report Summary

Cleaning Trial Type: Aqueous

Industry: Remanufacturing

Segment: 2 Automotive Retail

Soil: Oil, rust/oxides

Substrate: Steel, aluminum

Description of Part(s): Housing unites/connectors

Customer objective: Improve cleaning performance, reduce cleaning costs, recover scrap parts

Cleaner used: 5% by volume ArmaKleen™ BIO-24

Machine used: Spray Washer (JRI FL 250, JRI FL 500, JRI TL 3)

Temperature used: 160°F

Time required: 1-2 hours

Post Cleaning: Fresh water rinse and air pressure dried, followed by drying in an incubator at 220°F

Recommendation to Customer: The ArmaKleen Technical Center recommends using a 5% by volume solution of ArmaKleen™ Bio 24 at 160°F in a Spray Washer for a minimum of 1-2+ hours

Before Picture



After Picture



Source: TSR #19-A-018