ArmaKleen Technical Service Report Summary

Cleaning Trial Type: Aqueous

Industry: Remanufacturing

Segment: Auto Retail

Soil: Oil

Substrate: Aluminum

Description of Part(s): Rings

Customer objective: Improve cleaning performance, reduce rework and reject rate

Cleaner used: 5% by volume solution of ArmaKleen[™] 4 in 1 Cleaner

Machine used: Spray Washer (JRI FL 250, JRI FL 500, JRI TL 3)

Temperature used: 160°F

Time required: 15 minutes

Post Cleaning: Fresh water rinse and air pressure dried

Recommendation to Customer: The ArmaKleen Technical Center recommends using a 5% by volume solution of ArmaKleen™ 4 in 1 Cleaner at 160°F in a Spray Washer for a minimum of 15 minutes

Before Picture



After Picture



Source: TSR #18-A-026