

ArmaKleen Technical Service Report Summary

Cleaning Trial Type: Aqueous

Industry: Tool Cutting Manufacturer

Segment: 28 – Mfg – Machine (incl Medical)

Soil: Shop dirt, oil and grime

Substrate: Steel

Description of Part(s): five 5" diameter steel rings

Customer objective: The customer was looking to improve their cleaning performance

Cleaner used: 5% by volume solution of ArmaKleen™ 4 in 1 Cleaner

Machine used: Ultrasonic Washer (SK Blackstone Model 6315)

Temperature used: 160°F

Time required: 15 minutes to 1 hour

Post Cleaning: Fresh water rinse followed by air pressure drying

Recommendation to Customer: The ArmaKleen Technical Center recommends using a 5% by volume solution of ArmaKleen™ 4 in 1 Cleaner at 160°F in an Ultrasonic Washer for 15 minutes to 1 hour.

Before Picture



After Picture



Source: TSR #17-A-058