

ArmaKleen Technical Service Report Summary

Cleaning Trial Type: Aqueous

Industry: Communications

Segment: 86 Entertainment & Recreation Services

Soil: Calcified bird feces, grime, shop dirt

Substrate: Magnesium-coated aluminum, stainless steel, plastic

Description of Part(s): Radio tower housings

Customer objective: Improve cleaning performance, reduce cleaning costs, eliminate hazardous chemicals/waste

Cleaner used:

- 5% by volume ArmaKleen™ BIO-24
- 5% by volume ArmaKleen™ M-Aero

Machine used: Spray Washer (JRI FL 250, JRI FL 500, JRI TL 3)

Temperature used: 150°F

Time required: 10-15 minutes

Post Cleaning: No rinse and air pressure dried

Recommendation to Customer: The ArmaKleen Technical Center recommends using a 5% by volume solution of ArmaKleen™ Bio 24 at 150°F in a Spray Washer for a minimum of 10-15 minutes

Before Picture



After Picture

